

# 2015 - 2016 Corvette Z06 / Z07: Service News: Important Carbon Fiber Rocker Molding Installation Instructions for Z06/Z07

**GM CUSTOMER CARE & AFTERSALES  
URGENT - DISTRIBUTE IMMEDIATELY**

**DATE** October 28, 2015

**SUBJECT** Important Carbon Fiber Rocker Molding Installation  
Instructions for Z06/Z07

**MODELS** 2015-2016 Corvette Z06/Z07 with 8 Speed Automatic  
Transmission

**TO** All Chevrolet Dealers

**ATTN** Sales Managers, Service Managers, Service Technicians, New Car  
Prep Technicians

Please share this information with your New Vehicle Prep Department and  
Service Technicians that perform the pre-delivery inspections for 2015  
Corvettes.

**IMPORTANT:** It has come to our attention that if you do not use a drill bit  
collet on the drill bit when drilling the holes for the rivets that attach the loose  
shipped carbon fiber rocker panels, It may be possible to drill a hole through  
the transmission cooler lines for the front auxiliary cooler.

Please make sure to drill all holes perpendicular to the outside surface. Also  
make sure to use a drill bit collet to control bit depth to only 12mm max into  
the rocker.

The photo below shows the location of the automatic transmission cooler  
lines with the body's rocker molding removed.



Online URL:

<https://www.corvetteactioncenter.com/tech/knowledgebase/article/2015-2016-corvette-z06-z07-service-news-important-carbon-fiber-rocker-molding-installation-instructions-for-z06-z07-1266.html>