

# 1981 Corvette: ECM Codes

- Code #12: No Distributor Reference Pulse.
- Code #13: Oxygen Sensor Circuit.
- Code #14: Shorted Coolant Sensor Circuit.
- Code #15: Open Coolant Sensor Circuit.
- Code #21: Throttle Position Sensor Circuit.
- Code #23: Mixture Control Solenoid Circuit.
- Code #24: Vehicle Speed Sensor Circuit.
- Code #32: Baro Sensor Circuit Low.
- Code #34: Vacuum Map Sensor Circuit.
- Code #44: Oxygen Sensor Lean.
- Code #45: Oxygen Sensor Rich.
- Code #51: Faulty or Mis-Installed PROM.
- Code #52: Faulty ECM.
- Code #53: Faulty ECM.
- Code #54: Shorted Mixture Control Solenoid.
- Code #55: Faulty Oxygen Sensor or ECM.

Online URL:

<https://www.corvetteactioncenter.com/tech/knowledgebase/article/1981-corvette-ecm-codes-693.html>