

# 1968 Corvette: United Delco Bulletin: Universal Horns

---

Below is a chart issued in a United Delco Bulletin, 1A-93-12 - January 1968 regarding replacement horns for all passenger cars including the 1968 Corvette.

# 12 VOLT APPLICATION INFORMATION

## FOR **Delco Remy** REPLACEMENT HORNS

X—Indicates the tone of the horn/s presently on the vehicle and the part numbers heading these columns should be used for service replacement.

## FOR **Delco Remy** KLAXON® QUARTET

When selecting the additional horn/s for the KLAXON® QUARTET, install models indicated by the word "Add".

Make	Year	Penetone 1999935	Hi-Tone 9000514	Lo-Tone 9000239	Deep Tone 9000236	Make	Year	Penetone 1999935	Hi-Tone 9000514	Lo-Tone 9000239	Deep Tone 9000236
Ambassador	All	add	X	X	add	IHC Truck	All	add	X	add	add
American (Rambler)	All	add	X	X	add	Imperial	All	add	X	X	add
Barracuda (Plymouth)	All	add	X	X	add	Javelin (AMC)	All	add	X	X	add
Belvedere (Plymouth)	All	add	X	X	add	Jeep	All	add	*	*	add
Bronco (Ford)	All	add	X	X	add	Jeep Wagon	All	add	X	X	add
Buick	All	add	X	X	add	Lancer	All	add	X	X	add
Cadillac	53-63	add	X	X	add	Lincoln	56-66	add	X	X	add
Cadillac	64-68	X	X	X	add	Lincoln	67-68	add	X	X	X
Camaro	All	add	X	X	add	Mercury	All	add	X	X	add
Charger (Dodge)	All	add	X	X	add	Metrol (IHC)	All	add	X	add	add
Checker Motors	All	add	X	X	add	Montego (Comet)	All	add	X	X	add
Chevelle	All	add	X	X	add	Mustang	All	add	X	X	add
Chevrolet	All	add	X	X	add	Nash	All	add	X	X	add
Chevrojet Truck	All	add	add	X	add	Oldsmobile	53-65	add	X	X	add
Chevy II	All	add	X	X	add	Oldsmobile	66-68	add	add	X	X
Chrysler	All	add	X	X	add	Opel	All	add	*	*	add
Coronet	All	add	X	X	add	Packard	All	add	X	X	add
Corvair	All	add	X	X	add	Plymouth	All	add	X	X	add
Corvette	All	add	X	X	add	Polaris (Dodge)	All	add	X	X	add
Cougar (Mercury)	All	add	X	X	add	Pontiac	55-65	add	X	X	add
Dart (Dodge)	All	add	X	X	add	Pontiac	66-68	add	add	X	X
Desoto	All	add	X	X	add	Rambler	All	add	X	X	add
Dodge	All	add	X	X	add	Rebel (AMC)	All	add	X	X	add
Dodge Truck	All	add	add	X	add	Riviera	All	add	X	X	add
Edsel (Ford)	All	add	X	X	add	Road Runner (Plym.)	All	add	add	add	add
Eldorado	All	X	X	X	add	Scout (IHC)	All	add	add	X	add
F-85	All	add	X	X	add	Special	All	add	X	X	add
Fairlane	All	add	X	X	add	Studebaker	All	add	X	X	add
Falcon	All	add	X	X	add	Studebaker Truck	All	add	add	X	add
Firebird	All	add	X	X	add	Tempest	61-65	add	X	X	add
Ford	All	add	X	X	add	Tempest	66-68	add	add	X	X
Ford Truck	All	add	X	X	add	Thunderbird	All	add	X	X	add
Fury (Plymouth)	All	add	X	X	add	Toronado	All	add	add	X	X
GMC Truck	All	add	add	X	add	Valiant	All	add	X	X	add
Hudson	All	add	X	X	add	Volkswagen	All	add	*	*	add

\*Use Dual Horn set 1880227 12-volt package

Online URL:

<https://www.corvetteactioncenter.com/tech/knowledgebase/article/1968-corvette-united-delco-bulletin-universal-horns-946.html>