# 1968 Corvette: United Delco Bulletin: Universal Horns

Below is a chart issued in a United Delco Bulletin, 1A-93-12 - January 1968 regarding replacement horns for all passenger cars including the 1968 Corvette.

### 12 VOIT APPLICATION IN COMMINION

## FOR **Delco Remy**REPLACEME ... HORNS

X—Indicates the tone of the horn/s presently on the vehicle and the part numbers heading these columns should be used for service replacement.

#### FOR Delco Remy

When selecting the additional horn/s for the KLAXON®QUARTET, install models indicated by the word "Add".

Make	Year	Penetone 1999935		Lo-Tone 9000239	Deep Tone 9000236	Make	Year	Penetone 1999935	Hi-Tone 9000514	Lo-Tone 9000239	
Ambassador	All	add	х.	х	add	IHC Truck	AII	add	х	add	add
American (Rambler)	All	add	x	×	add	Imperial	All	add	×	×	add
Barracuda (Plymouth)	All	add	×	×	add	Javelin (AMC)	All	add	×	×	add
Belvedere (Plymouth)	All	add	X	X	add	Jeep	AII	adc			add
Bronco (Ford)	All	add	х	x	add	Jeep Wagon	All	adc	X	х	add
Buick	AII	add	×	X	add	Lancer	All	add	x	x	add
Cadillac	53-63	add	×	x	add	Lincoln	56-66	add	х	х	add
Cadillac	64-68	х	x	x	add	Lincoln	67-68	add	x	×	X.
Camaro	AII	add	x	x	add	Mercury	All	adc	х	×	add
Charger (Dodge)	All	add	х	х	add	Metro (IHC)	All	add	x	add	add
Checker Motors	All	add	х	x	add	Montego (Comet)	All	add	x	×	add
Chevelle	All	add	x	x	add	Mustang	AII	adc.	х	×	add
Chevrolet	All	add	х	x	add	Nash	AII	add	х	х	add
Chevrolet Truck	All	add	add	x	add	Oldsmobile	53-65	adci	x	x	add
Chevy II	All	add	х	x	add	Oldsmobile	66-68	adc	add	x	х
Chrysler	All	add	х	x	add	Opel	All	add			add
Coronet	All	add	х	X	add	Packard	All	adc	Х	X	add
Corvair	All	add	X	.<	add	Plymouth	All	adc	х	х	add
Corvette	All	add	х	.<	add	Polara (Dodge)	All	adc	х	х	add
Cougar (Mercury)	All	add	X	<b>S</b> .	add	Pontiac	55-65	adc.	х	х	add
Dart (Dodge)	All	add	X	Χ.	add	Pontiac	66-68	adci	add	х	Х
Desoto	All	add	х	×	add	Rambler	AII	add	x	x	add
Dodge	All	add	x	×	add	Rebel (AMC)	AII	add	х	х	add
Dodge Truck	All	add	add	х	add	Riviera	All	add	х	x	add
Edsel (Ford)	All	add	х	X	add	Road Runner (Plym.)	All	adc	add	add	add
Eldorado	All	X	X	x	add	Scout (IHC)	All	add	add	х	add
F-85	AII	add	X	X	add	Special	AII	adc'	х	х	add
Fairlane	All	add	х	X	add	Studebaker	All	adci	х	x	add
Falcon	All	add	X	X	add	Studebaker Truck	All	add	add	X	add
Firebird	All	add	Х	х	add	Tempest	61-65	add	Х	х	add
Ford	All	add	х	х	add	Tempest	66-68	add	add	х	X
Ford Truck	AII	add	х	x	add	Thunderbird	All	add	х	х	add
Fury (Plymouth)	AII	add	х	x	add	Toronado	AII	add	add	х	Х
GMC Truck	All	add	add	x	add	Valiant	All	add	х	х	add
Hudson	II.A	add	х	X	add	Volkswagen	All .	adc			add

<sup>\*</sup>Use Dual Horn set 1880227 12-volt package

### Online URL:

https://www.corvetteactioncenter.com/tech/knowledgebase/article/1968-corvette-united-delco-bulletin-universal-horns-946.html