

# 1994 - 1996 Corvette: Diagnostic Trouble Codes

DTC #11: Malfunction Indicator Lamp Circuit.

DTC #13: Bank #1 Heated Oxygen Sensor #1 Circuit:

DTC #14: Engine Coolant Temperature Sensor Circuit Voltage Low.

DTC #15: Engine Coolant Temperature Sensor Circuit Voltage High.

DTC #16: Distributor Ignition System Low Pulse.

DTC #18: Injector Circuit.

DTC #21: Throttle Position Sensor Circuit Voltage High.

DTC #22: Throttle Position Sensor Circuit Voltage Low.

DTC #23: Intake Temperature Sensor Circuit Voltage High.

DTC #24: Vehicle Speed Sensor Circuit.

DTC #25: Intake Air Temperature Sensor Circuit Voltage Low.

DTC #26: Evaporative Emission Canister Purge Solenoid Valve Circuit.

DTC #27: EGR Vacuum Control Signal Solenoid Valve Circuit.

DTC #28: Transmission Range Pressure Switch Assembly Fault.

DTC #29: Secondary Air Injection Pump Circuit.

DTC #32: Exhaust Gas Recalculation.

DTC #33: Manifold Absolute Pressure Sensor Circuit High.

DTC #34: Manifold Absolute Pressure Sensor Circuit Low.

DTC #36: Distributor Ignition System High Pulse.

DTC #37: Brake Switch Stuck On.

DTC #38: Brake Switch Stuck Off.

DTC #41: Ignition Control Circuit Open.

DTC #42: Ignition Control Circuit Shorted.

DTC #43: Knock Sensor Circuit.

DTC #44: Bank 1 LF Heated Oxygen Sensor #1 Circuit Lean.

DTC #45: Bank 1 LF Heated Oxygen Sensor #1 Circuit Rich.

DTC #47: Knock Sensor Circuit Or Module Missing.

DTC #48: Mass Air Flow Sensor Circuit.

DTC #50: System Voltage Low.

DTC #51: EPROM Programming Error.

DTC #52: Engine Oil Temperature Sensor Circuit Voltage Low.

DTC #53: System Voltage Low.

DTC #55: Fuel Lean Monitor.

DTC #58: Transmission Fluid Temperature Sensor Circuit Low.

DTC #59: Transmission Fluid Temperature Sensor Circuit High.

DTC #62: Engine Oil Temperature Sensor Circuit Voltage Low.  
DTC #63: Bank 2 RF Heated Oxygen Sensor #1 Circuit Open.  
DTC #64: Bank 2 RF Heated Oxygen Sensor #1 Circuit Lean.  
DTC #65: Bank 2 RF Heated Oxygen Sensor #1 Circuit Rich.  
DTC #66: A/C Refrigerant Pressure Sensor Circuit Open.  
DTC #67: A/C Pressure Sensor Circuit Sensor or A/C Clutch.  
DTC #68: A/C Relay Circuit.  
DTC #69: A/C Clutch Circuit.  
DTC #70: A/C Clutch Relay Driver Circuit.  
DTC #72: Vehicle Speed Sensor Loss.  
DTC #73: Pressure Control Solenoid Circuit Current Error.  
DTC #74: Traction Control System Circuit Low.  
DTC #75: Transmission System Voltage Low  
DTC #77: Primary Cooling Fan Relay Control Circuit.  
DTC #78: Secondary Cooling Fan Relay Control Circuit.  
DTC #79: Transmission Fluid Overtemp.  
DTC #80: Transmission Component Slipping.  
DTC #81: Transmission 2-3 Shift Solenoid Circuit.  
DTC #82: Transmission 1-2 Shift Solenoid Circuit.  
DTC #83: Torque Converter Solenoid Voltage High.  
DTC #84: 3-2 Control Solenoid Circuit.(Auto Only).  
DTC #84: 2nd And 3rd Gear Blockout Relay Control Circuit.  
DTC #85: Transmission TCC Stock On.  
DTC #90: Transmission TCC Solenoid Circuit.  
DTC #91: One To Four Upshift Lamp(Manual Only).  
DTC #97: VSS Output Circuit.  
DTC #98: Tachometer Output Signal Voltage Wrong.

Online URL:

<https://www.corvetteactioncenter.com/tech/knowledgebase/article/1994-1996-corvette-diagnostic-trouble-codes-551.html>