

# 1968 Corvette: Service News: Headlamp Aiming Procedure

---

**Subject:** Headlamp Aiming Procedure

**Model and Year:** 1968 Corvette

**Source:** Chevrolet Service News

**Page Number:** NA

**Date:** November 1967 - Volume 39 - Number 10

## 1968 Corvette Headlamp Aiming Procedure

Do **not** aim the headlamps on a 1968 Corvette until you are sure that they are in their operating position. The only way to be certain that they are in operation position, is to have the system under at least 20 inches vacuum. To determine the amount of vacuum in the system, place a vacuum gauge (set-up as shown in figure 5) between the vacuum tank and the supply hose. Once the vacuum gauge has been installed in the system as shown in figure 5, run the engine for approximately two (2) minutes. Turn off the engine and read the gauge. It should read at least 20 inches Hg. If it does not, check for a leak in the system or a plugged or kinked hose between the manifold and the vacuum tank.

Once 20 inches of vacuum is obtained, aim the headlamps in the normal manner.




Fig. 5—Install Vacuum Gauge Between Vacuum Tank and Supply Hose

Online URL:

<https://www.corvetteactioncenter.com/tech/knowledgebase/article/1968-corvette-service-news-headlamp-aiming-procedure-1205.html>